Features:

· Advanced 2.4 GHz wireless with long-range connection eliminates delays, drop-outs and interference.

· Smart battery system with multiple battery-save modes including sleep when idle.

· Receiver stowed in mouse for transportation.

· Requires 1 x AAA battery for mouse and 2 x AAA for keyboard.

Installation:

1. Slide open mouse battery cover, remove wireless receiver and insert into free USB slot on computer.

2. Insert 1 x AA battery into mouse (negative end first), replace battery cover and switch on.

3. Remove battery cover on underside of keyboard.

4. Insert 2 x AAA battery and replace battery cover.

System compliance:
Windows ME/2000/XP/Vista/7 Android OS

Trouble shooting:
Q1: No reaction from keyboard or mouse A1: Check battery polarity. Check on/off switch. Check battery has charge.

Q2: Mouse laser light off or flashing: A2:Change to suitable mousing surface. Clean lens on underside of mouse.

Important:
· Exterior of mouse and keyboard may be cleaned with dry, clean cloth.
· Uneven surface may not be suitable for mouse tracking.
· Do not disassemble mouse or keyboard for maintenance.
· Remove battery if mouse and keyboards are not to be used for long periods of time.
· Do not use Bluetooth devices in close proximity to wireless set.
· At end of product life, please dispose of this product in accordance with local regulations.