


How to set up your solo #pad keyboard

System requirements:

PC with Windows XP, Windows Vista, Win 7, Win 8, Win 10

How to set up the keyboard:

1. On the right side of the keyboard, switch the ON/OFF button to ON.
2. Insert the USB dongle provided into one of the PC's USB ports. The keyboard features plug-n-play software, so there is no additional action required.
3. If keyboard does not function correctly, then reset as described below.



LED light functions:

There are 3 LEDs on the right upper corner of the keyboard:

1. Lower: Battery status. RED When battery is low. RED when charging via USB turning GREEN when fully charged.
2. Middle: Blue when USB dongle gets connected to the computer and communication between keyboard and computer is active.
3. Upper: Blue When Caps Lock is active

Multimedia Hotkeys functions

- | | |
|------------------------|---------------------|
| FN+ESC=Media Player | FN+F7= Web home |
| FN+F1=Play/Pause | FN+F8= Search |
| FN+F2=Previous Track | FN+F9= Favorite |
| FN+F3=Next Track | FN+F10= Email |
| FN+F4=Volume Up | FN+F11=Screen Lock |
| FN+F5=Volume Down | FN+F12= My computer |
| FN+F6= Mute (Windows) | |

How to recharge:

On the right side of the keyboard there is a micro-USB slot. To recharge from the PC directly use only the cable provided or alternatively use a standard phone charger with no power charging function.

How to Reset:

In case the keyboard encounters error in communication with the computer, follow the steps below to reset to the factory settings:

1. Check if the battery level is too low. If lower LED is RED, then recharge is required.
2. Turn off the keyboard. Insert the USB dongle in the PC's USB port. Place the keyboard very close to the dongle, keep pressing the CTRL key while the keyboard is being turned on.

Riser strip:

A magnetic riser strip is included with the keyboard and if required it will self- locate to the embedded magnets at the top of the keyboard base.

WARNING:

To recharge from the PC directly use one only the cable or alternatively use a standard phone charger with no power charging function.

